

Key description

- Contrast** Cycles through eight settings to adjust the display contrast.
- Directory** Lets you store and access up to 50 numbers and names.
- Save** Stores numbers and names in the Directory and in memory keys.
-  Lets you move up and down any list such as the Set Options, Directory, Callers List, or Redial list.
-  Lets you backspace and erase when predialing and when adding or changing numbers and names in the Directory, Callers List, or in memory keys.
-  Adds a space when entering names in the Directory or in memory keys. Lets you view status messages on the display.
-  Hidden unlabeled Set Options key under the sliding panel lets you access eight options to customize your telephone.
- Hold** Puts the call on hold.
- Rls** Always hangs up a call. Lets you leave any list such as the Directory, Set Options, Callers List, or Redial list.
- Callers** Lets you access a list of people who called.
- Delete** Lets you erase memory keys and delete items in the Directory and Callers List.
- Link** Allows you to access network features such as call waiting (may be called Flash).
- Redial** Lets you access a list of the last five numbers you dialed.

- Dial** Selects your line and dials any displayed number. Puts you on Handsfree if you haven't lifted the handset.
- Handsfree Mode** Activates the speaker and microphone so you can listen and talk without lifting the handset.
-  Lets you adjust the receiver, speaker, and ringer volume.
-  Memory keys store numbers, names, and features.

